

INSTALLATION INSTRUCTIONS

KOOL KAPS ENGINE KIT FOR INDIAN® TOURING, SATIN BLACK

2471

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Kool Kaps Engine Kit Including:
 - 33 Kool Kaps for M6 Socket Head Cap Screws (uses 6mm Allen Key)
 - 19 Kool Kaps for M8 Socket Head Cap Screws (uses 5mm Allen Key)

YOU WILL ALSO NEED:

Silicone Adhesive

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

NOTE: Sizes listed for Kool Kaps is the fastener size, not the wrench size.

NOTE: Not all Kool Kaps will be used for every application. If do not use all the Kool Kaps in the suggested areas, you may use them on any appropriate sized fastener on the bike. The following are suggested locations.

NOTE: Kool Kaps are designed to friction fit over METRIC fasteners. In case the fit is not tight enough for your satisfaction, we recommend using a silicone adhesive to ensure the Kool Kaps stay in place. Apply a small amount of the silicone to the Kool Kap and press it in place. Remember, silicone expands as it dries, so using a little less will help keep the Kool Kap tight to the fastener head when the silicone dries. The silicone will fully cure in 24 hours.

NOTICE DO NOT USE ANY OTHER TYPE OF GLUE TO ADHERE THE KOOL KAPS TO ANY FASTENER, EXCEPT FOR SILICONE ADHESIVE.

INSTALLATION INSTRUCTIONS

KOOL KAPS ENGINE KIT FOR INDIAN® TOURING, SATIN BLACK

2471

-CONTINUED-

M6 SOCKET HEAD KOOL KAPS

- 8 Inner Primary Cover
- 6 Pushrod Base Cover
- 4 Sprocket Cover
- 10 Cam Cover
- 5 Extras

M8 SOCKET HEAD KOOL KAPS

- 14 Outer Primary Cover
- 5 Extras

CAUTION

ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE BEFORE RIDING.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.