

INSTALLATION INSTRUCTIONS

PIPE WRENCH FORK MOUNTS FOR CUSTOM LIGHTS

2579 CHROME, 2580 SATIN BLACK

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

2	Front Mount	1	Hardware Kit, containing:
2	Rear Mount	2	1/4-20 x 1" Socket Head Cap Screws
2	Mount Insert 49mm	2	1/4-20 x .625" Socket Head Cap Screws
2	Mount Insert 41mm	2	1/4"-20 X 3/8" Set Screw
2	Mount Insert 39mm		

YOU WILL ALSO NEED:

Hex wrench set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** Locate provided one (1) Front Mount, one (1) Rear Mount, one (1) of each Mount Inserts, and one (1) of each Socket Head Cap Screw. Test fit what insert and socket head cap screw will work best for your fork mount application.
- STEP 3** Refer to PIC 2 and 3. Once insert and hardware has been determined, loosely fasten the Front Mount, Mount Insert, and Rear Mount together using the Socket Head Cap Screw.
- STEP 4** Refer to PIC 3. Locate sold separately light with M8 threaded stud. Fasten the light to the Rear Mount and secure it in place using the provided Set Screw.
- STEP 5** Refer to PIC 4 through 6. With the loosely assembled mounts, align and place the rear mount on the back side of the fork, hooking the front mount and insert around the side. Slide the Front Mount into position over the front of the fork, be sure the insert is properly aligned in between both mounts.



INSTALLATION INSTRUCTIONS

PIPE WRENCH FORK MOUNTS FOR CUSTOM LIGHTS

-CONTINUED-

STEP 6 Refer to PIC 7. Adjust the mount assembly to desired position. Fully tighten hardware to secure the mount assembly in place.

STEP 7 Repeat steps 3 through 6 for the opposite side.

STEP 8 Install the lights per the instructions provided with them.



WARNING ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE BEFORE RIDING.

NOTICE IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.