






WINDSHIELD SIDE TRIMS for '15-UP ROAD GLIDE, GLOSS BLACK

2633

THANK YOU FOR CHOOSING KÜRYAKYN!

PROTECT YOURSELF AND OTHERS FROM POSSIBLE INJURY AND PROPERTY DAMAGE OR LOSS. PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS, AND NOTICES REGARDING THE INSTALLATION, USE, AND CARE OF THIS PRODUCT.


 WARNING	THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
 CAUTION	This indication alerts you to the fact that ignoring the contents described herein can result in minor or moderate potential injury.
 NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

MAKE SURE THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right Windshield Trim
- 1 Right Gasket
- 1 Left Windshield Trim
- 1 Left Gasket
- 1 Installation Instructions

YOU WILL ALSO NEED:

Warm, soapy water and a clean rag, #2 Phillips Head Screwdriver

 **NOTICE** These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future reference.

STEP 1 Read and understand all **STEPS** in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn **IGN OFF**.

STEP 2 Prepare a soft, sturdy work surface at a comfortable height near the motorcycle.

 **NOTICE** Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

STEP 3 Refer to **PIC 1**. Using warm, soapy water and a clean rag, remove all dirt and debris from the installation area; allow the area to dry completely.

STEP 4 Remove the two existing screws from the clutch-side (left) of the windshield; set them aside they will be reused. Remove the screws from the other side.

STEP 5 Ensure that the windshield rests on the existing rubber seal as shown in **PIC 1**.



STEP 6 Position the Left Gasket as shown in **PIC 2 and 3**; place the Left Trim over the Gasket.



STEP 7 Refer to **PIC 3**. Secure the Trim with two of the existing screws.



STEP 8 Repeat **STEPS 5, 6, and 7** for the other side.

NOTICE

It is the end user's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

Ride On!