



**CHROME TRUNK KEY HOLE TRIM 3219**

**FITS: ALL '01-UP GL1800 MODELS**

**PARTS INCLUDED**

- 1 Chrome Trunk Key Hole Trim
- 1 Alcohol Pad
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**STEP 2** As shown in PIC 1, test fit the Chrome Trunk Key Hole Trim over the key hole on the trunk. Using masking tape, mark the location of best fit to aid in final installation of the Key Hole Trim.

**ATTENTION!** The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

**STEP 3** Clean the mounting area on the trunk. Clean using a mild cleaner (window cleaner) to remove any wax or polish residue on the surface. Wipe clean with the included alcohol pad and wipe dry with a clean cloth.

**ATTENTION!** Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

**STEP 4** Rub the adhesive backing on the Key Hole Trim to activate the adhesive. Remove the adhesive backing and apply the Key Hole Trim to the trunk using any marks made in Step 2 as a guide.

**STEP 5** Press and hold the Trim in place for one minute, full bonding strength will occur in 24 hours.



*Ride On!*