



L.E.D. REAR FENDER TIP W/RUN-BRAKE ACCENT

3236



PARTS INCLUDED


- 1 L.E.D. Chrome Rear Fender Trim
- 1 Double "Y" Adapter
- 1 Hardware Kit Containing:
 - 2 6mm Spacers
 - 2 M6 Narrow Flat Washers
 - 2 M6 X 1.0 X 25mm Button Socket Cap Screws
 - 4 4" Black Nylon Cable Ties
 - 1 Dielectric Grease Pack
 - 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

 WARNING	THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
 NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

 NOTICE	IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.
--	---

TOOLS SUGGESTED

Set of Metric Hex Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

NOTE: This product requires the motorcycle to be equipped with Kuryakyn Rear Accessory Plug and Play Harness, P/N 3230.

STEP 2 Thoroughly clean the bottom of the rear fender panel with soapy water and a clean rag. PIC 1 Rinse and dry completely. Wipe the area with the included alcohol pad to remove any residue. Dry completely.

 NOTICE	Ensure the area of installation is free of grease, oil, dirt or other debris including wax/polish products and bugs to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.
--	--

STEP 3 Remove the four fasteners securing the rear fender panel to the motorcycle. Set these aside, the top two will be reused. PIC 2 Remove the fender panel.

NOTICE Küryakyn recommends the use of dielectric grease on electrical connections.

STEP 4 Please refer to the instructions for P/N 3230: If you have an open six pin connector on the Plug and Play Harness (P/N 3230), apply some of the included dielectric grease and connect the six pin connector from the Rear Fender Tip to it. If you do not have an open connector, disconnect one of the six pin sets, apply some of the included dielectric grease to all connectors and connect the included Double "Y" connector in line. PIC 5 Connect the existing accessory and the Rear Fender Tip to the new Double "Y" connector. Use the included cable ties to secure the harness out of harms way.

NOTICE Secure all wiring away from any moving parts, pinch points or extreme heat. Küryakyn WILL NOT issue a warranty on any electrical component that fails due to pinched, crimped, broken, abraded, melted or frayed wires.

STEP 5 Install the rear fender panel to the motorcycle using the top two fasteners from Step 3.

STEP 6 Rub the adhesive backing with the back of your fingernail to activate the adhesive. Remove the backing. Attach the Rear Fender Trim to the bottom of the rear fender panel by placing one of the included flat washers, then a spacer over the threads of each of the included M6 button head cap screws. PIC 3 Then, inserting them through the Rear Fender Trim, thread them into the boss on the motorcycle. PIC 4 Make sure the spacer goes into the recessed hole in the rear fender panel before tightening the cap screw. Tighten securely, but **DO NOT OVER TIGHTEN** these. Press the top of the Trim firmly for one minute to attach the adhesive. Full bonding will occur in 24 hours.





NOTE: The adhesive tape on the Rear Fender Accent is used as a buffer, it is not meant to completely secure the Accent to the fender panel.

NOTICE This Rear Fender Accent will fit with a trailer hitch, but check all clearances when connecting the trailer to the motorcycle.

STEP 8 Test all lights for proper function.

WARNING ENSURE PROPER LIGHT OPERATION BEFORE RIDING THE MOTORCYCLE. VISIBILITY IS A MAJOR CONCERN FOR MOTORCYCLISTS. A LIGHT MALFUNCTION COULD RESULT IN DEATH OR SERIOUS INJURY.

NOTICE It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to improper installation. Periodic maintenance may be required.



Ride On!