

## INSTALLATION INSTRUCTIONS

### OMNI WINDSHIELD ACCENTS FOR GL1800

3277

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE**

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Left Accent
- 1 Right Accent

#### YOU WILL ALSO NEED:

An Awl

**NOTICE**

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

**STEP 2** Position the windshield up to gain access to the backside of the existing windshield accents.

**STEP 3** Refer to PIC 2. On the backside of the windshield push on the pop rivets to release the existing accent pieces from the windshield. Set pop rivets aside, they will be reused.

**STEP 4** From the front of the windshield press downward on the existing accents to unhook it from the windshield. Remove accents.

**STEP 5** Refer to PIC 3. Locate provided Left and Right Accent.

*Note: Take note of the stampings made on the hooks on the backside of the accents.*

*L = Left (clutch-side)  
R = Right (brake-side)*

**STEP 6** Refer to PIC 4. Align and insert the hook of the new accent, per their respective side, with the hole in the windshield from where there previous accent was hooked into. Slide the accent up and secure it in place with the pop rivet that was removed in Step 3.



PIC 1



PIC 2



PIC 3

PIC 4

## INSTALLATION INSTRUCTIONS

### OMNI WINDSHIELD ACCENTS FOR GL1800

3277

-CONTINUED-

#### **NOTICE**

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

**FINAL**

