

INSTALLATION INSTRUCTIONS

RIOT SHIFT LINKAGE FOR MID CONTROL DYNA MODELS, SATIN BLACK

3571

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Shift Linkage
- 2 5/16-24 X 1 Button Socket Cap Screw
- 1 Flat Washer

YOU WILL ALSO NEED:

Hex key set, combination wrench set

PICTURES SHOWN ARE OF THE SILVER PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** Refer to PIC 2. Remove existing shift linkage and hardware. Set them aside, they will not be reused.
- STEP 3** Locate provided Shift Linkage. Adjust the length of it to match the length of the removed shift linkage, by twisting the ball joint rod end in or out. Once at the desired length, tighten the nut down to the surface of the shift linkage. Fully tighten the nut.
- STEP 4** Refer to PIC 3. Locate provided one (1) provided screw. Align and fasten the shift linkage, ball joint rod end, to the rear shift arm using the screw.
- Note: Be sure the Kuryakyn shield logo is located on the back side of the shift linkage when installed.*
- STEP 5** Located provided one (1) screw and flat washer.
- STEP 6** Refer to PIC 4. Align and fasten the front of the shift linkage to the front shift arm by aligning the washer in between the shift arm and shift linkage, and inserting the screw through all of them. Fully tighten hardware.



PIC 1



PIC 2



PIC 3



PIC 4



INSTALLATION INSTRUCTIONS

RIOT SHIFT LINKAGE FOR MID CONTROL DYNA MODELS, SATIN BLACK

3571

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

