

## INSTALLATION INSTRUCTIONS

### RIOT SHIFT LINKAGE FOR FORWARD CONTROL SPORTSTER MODELS, SATIN BLACK 3573

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Shift Linkage

#### YOU WILL ALSO NEED:

Hex key set, combination wrench set

PICTURES SHOWN ARE OF THE SILVER PART. INSTALLATION OF THE BLACK PART WILL BE THE SAME.

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** Refer to PIC 2. Remove existing shift linkage and hardware. Set the hardware aside, it will be reused.
- STEP 3** Locate provided Shift Linkage. Adjust the length of it to match the length of the removed shift linkage, by twisting the ball joint rod end in or out. Once at the desired length, tighten the nut down to the surface of the shift linkage. Fully tighten the nut.
- STEP 4** Refer to PIC 3. Locate OEM hardware that was removed in Step 2. Align and fasten the shift linkage, ball joint rod end, to the rear shift arm using the screw.
- Note: Be sure the Kuryakyn shield logo is located on the back side of the shift linkage when installed.*
- STEP 5** Refer to PIC 4. Align and fasten the front of the shift linkage to the front shift arm using the remaining OEM screw. Fully tighten hardware.

PIC 1



PIC 2



PIC 3



PIC 4





## INSTALLATION INSTRUCTIONS

RIOT SHIFT LINKAGE FOR FORWARD CONTROL SPORTSTER MODELS, SATIN BLACK 3573

-CONTINUED-

**NOTICE**

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

