

INSTALLATION INSTRUCTIONS

RIOT GRIPS FOR INDIAN® SCOUT, SATIN BLACK

3589

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|--------------------|---|----------|
| 1 | Clutch Side Grip | 2 | End Caps |
| 1 | Throttle Side Grip | 1 | Spacer |
| 1 | Adhesive | | |

YOU WILL ALSO NEED:

Torx drivers set, clean rag, ammonia based cleaner (Windex), 80-100 grit sand paper

PICTURES SHOWN ARE OF THE SILVER PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.



THROTTLE SIDE INSTALLATION

- STEP 2** Remove the four (4) screws on the back-side of the throttle-side switch housing, and separate the housing assembly.

- STEP 3** Refer to PIC 2. Note how the plastic throttle sleeve fits into the channel in the switch housing. Carefully slide the existing grip off of the handlebar.



- STEP 4** Refer to PIC 3. Locate provided Throttle Grip. Align and place the new grip onto the handlebar. Rotate the grip on the bar until it aligns with the switch housing, then slide it into place.



INSTALLATION INSTRUCTIONS

RIOT GRIPS FOR INDIAN® SCOUT, SATIN BLACK

3589

-CONTINUED-

- STEP 5** Refer to PIC 4. Reassemble the switch housing and secure it with the four (4) screws that were removed in Step 2.

PIC 4

- STEP 6** Refer to PIC 5. Locate one (1) provided End Cap. Align and insert it into the open end of the handlebar and grip. Do not push the End Cap all the way in, leave a very small gap between the grip and the end cap.



- STEP 7** With the end cap not entirely pushed in, use a hex key to tighten the flat head socket screw located on the end of the End Cap to secure it in place. Do not over tighten the screw.



PIC 5

CLUTCH SIDE INSTALLATION

- STEP 8** Refer to PIC 6. Remove the clutch-side grip from the handlebar. The grip may be glued to the handlebar and you may need to twist the grip to break the adhesive bond.

PIC 6

- STEP 9** Prepare the clutch-side handlebar for proper adhesion by sanding the surface with 80-100 grit sandpaper or emery cloth. Remove any glue residue from the handlebar.



- STEP 10** With an ammonia based cleaner (Windex) and a clean rag, remove any contaminants from the handlebar and the inside of the grip.

*Note: Determine the desired orientation of the clutch-side grip BEFORE gluing and installing. The supplied adhesive sets up **ALMOST INSTANTLY** in the absence of air. There is enough time to slide the grip into place, but **ONCE IT STOPS MOVING, IT CANNOT BE ADJUSTED.***

- STEP 11** Refer to PIC 7. Locate provided one (1) Spacer. Place the spacer onto the clutch side handlebar.



PIC 7

CAUTION

AVOID CONTACT WITH EYES, SKIN AND CLOTHING. AVOID BREATHING VAPORS OR MISTS OF THIS PRODUCT. WASH THOROUGHLY AFTER HANDLING. AVOID CONTACT WITH FABRIC OR PAPER GOODS. CONTACT WITH THESE MATERIALS MAY CAUSE RAPID POLYMERIZATION WHICH CAN GENERATE SMOKE AND STRONG IRRITATING VAPORS, AND CAUSE THERMAL BURNS.

INSTALLATION INSTRUCTIONS

RIOT GRIPS FOR INDIAN® SCOUT, SATIN BLACK

3589

-CONTINUED-

STEP 12 Refer to PIC 8. Test fit the Clutch Side Grip on the handlebar. **DETERMINE THE ORIENTATION OF THE GRIP BEFORE GLUING IT TO THE HANDLEBAR.**

STEP 13 Open the supplied tube of adhesive and squeeze all of the glue onto the inner side walls of the clutch-side grip. Rotating the grip while applying the glue will help distribute it evenly. Make sure you get the glue all the way to the end of the rubber insert in the grip.

STEP 14 In one smooth motion, slide the grip onto the handlebar and into position. Rotate it back and forth slightly as you slide it on to help distribute the glue evenly and keep the grip from “plowing” the glue up against the switch housing. **YOU MUST WORK QUICKLY TO GET THE DESIRED POSITION BEFORE THE GLUE DRIES. (APPROX. 6 SECONDS).**

STEP 15 Once in place, squeeze the grip firmly to press the rubber against the bar and hold for 15 seconds. Allow at least 30 minutes to cure before operating the motorcycle.

STEP 16 Refer to PIC 9. Locate one (1) provided End Cap. Align and insert it into the open end of the handlebar and grip.

STEP 17 Secure the End Cap in place by tighten the flat head socket screw located on the end of it. Do not over tighten the screw.

STEP 18 Ensure proper throttle and brake function BEFORE operating the motorcycle.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 8



PIC 9



FINAL