



STEREO ACCENT

3765

FITS: '96-UP ELECTRA GLIDES, STREET GLIDES AND TRIKES

PARTS INCLUDED

- 1 Stereo Accent
- 1 Stereo Cover
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

STEP 2 Test fit the Stereo Accent to the inner fairing.

NOTE *It may be helpful to remove the Stereo Cover before test fitting*

STEP 3 Mark the location of best fit using masking tape. This will help in final installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 4 Clean the entire mounting area on the inner fairing with the included alcohol pad. Wipe the area completely dry with a clean cloth.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

STEP 5 Rub the tape backing on the Stereo Accent to activate the adhesive. Remove the tape backing and apply the Accent to the inner fairing.

STEP 6 Press and hold the Accent in place for one minute. Full bonding strength will occur in 24 hours.

STEREO COVER

STEP 1 To install the Stereo Cover, hook the top of the cover under the Stereo Accent and press the lower portion of the Cover until it snaps in to place.

STEP 2 To remove the Stereo Cover, pull outward on the tabs at the bottom. The Cover should snap out of place.

Ride On!

Kuryakyn®

PIC. 1



PAGE

2

STEREO ACCENT

INSTALLATION