



SWITCH PANEL ACCENT 3783

FITS: '96-UP ELECTRA GLIDES AND '06-UP STREET GLIDES

PARTS INCLUDED

- 1 Dash Cover Assy.
- 3 Switch Cover Assy.
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

STEP 2 Wipe the area of installation free of grease, oil, dirt or other debris with the provided alcohol pad to ensure proper adhesion.

STEP 3 On the back of the switch panel accent cover, use your fingernail and rub the backing of the adhesive pad to activate the catalyst.

STEP 4 Remove the backing from the adhesive pad.



-cont.-

STEP 5 Center the Switch Panel Accent cover over the ignition switch and the accessory switches. Make sure that the Switch Panel Accent is pushed forward as far as possible to avoid contact with the Fuel Tank Console. (PIC 2)

CAUTION! Check for adequate clearance between the Switch Panel Accent and the Fuel Tank Console. It may be necessary to loosen and adjust the Fuel Tank Console to provide clearance.

STEP 6 Press and hold the accent in place for one minute. Full bonding strength will occur in twenty-four hours.

STEP 7 On the backside of the black switch covers, rub the adhesive backing pad to activate the catalyst.

STEP 8 Remove the adhesive backing pad.

STEP 9 Center the black switch covers over the unused switches.

STEP 10 Press and hold the switch cover in place for one minute. Full bonding strength will occur in twenty-four hours.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Kuryakyn WILL NOT issue a warranty on any parts lost due to improper installation.

Ride On!

PIC 2

