

INSTALLATION INSTRUCTIONS

LODESTAR KICKSTAND SHOE FOR BMW F 750 GS AND F 850 GS

3841 GOLD, 3842 BLACK OR 3843 SILVER

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

⚠ WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

⚠ CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Top Kickstand Shoe
- 1 Bottom Kickstand Shoe
- 3 M5 x 0.8 x 10mm Torx Flat Head Cap Screws

YOU WILL ALSO NEED:

Torx wrench set

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Set bike in up right position.

STEP 3 Locate provided Top and Bottom Kickstand Shoes and three (3) M5 screws.

STEP 4 Refer to FIG 1. Slide and align the bottom kickstand shoe under the existing kickstand. Slide the top kickstand shoe over the top of the existing kickstand. Align the mounting holes of the two shoes.

STEP 5 Refer to FIG 1 and PIC 2. From the bottom side of the kickstand and shoes, fasten and secure shoes in place using the provided M5 screws. Fully tighten hardware.

PIC 1



FIG 1

