

INSTALLATION INSTRUCTIONS

BOOMERANG FRAME COVERS WITH SCUFF PROTECTORS

3915

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

- WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
- CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.
- NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|-------------------|---|---|
| 1 | Left Frame Cover | 6 | M5 x .80 x 20mm, 3mm Shoulder, Button Socket Cap Screws |
| 1 | Right Frame Cover | 1 | Anti-seize |
| | | 2 | Alcohol Pads |

YOU WILL ALSO NEED:

Metric bit set and ratchet or metric allen key set

- NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.
- NOTICE** ENSURE PROPER ADHESION OF THIS PRODUCT. REMOVE ALL GREASE, OIL, BUGS, DIRT, AND OTHER DEBRIS (INCLUDING WAX AND POLISH) FROM THE INSTALLATION AREA. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION.
- DO NOT ATTEMPT THIS INSTALLATION IN TEMPERATURES BELOW 50°F (10°C). PROPER ADHESIVE BONDING ONLY OCCURS ABOVE 50°F (10°C).
- NOTICE** BE SURE TO USE THE SUPPLIED ANTI-SEIZE ON ALL THREADED FASTENERS BEFORE INSTALLATION. THIS WILL REDUCE GALLING AND MAKE FUTURE REMOVAL OF THE FASTENERS EASIER.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** Remove fasteners from stock swing arm pivot covers and remove the cover. (See PIC.1 and PIC.2.)
- STEP 3** Remove the stock, gray plastic covers from each side of the frame. The top of each gray cover is secured by a black plastic insert, the bottom is secured by two sided tape. To remove the plastic insert, carefully extract the pin found in the center of the insert until it stops, then remove the entire insert from the frame. (See PIC.3.)



INSTALLATION INSTRUCTIONS

BOOMERANG FRAME COVERS WITH SCUFF PROTECTORS

3915

-CONTINUED-

STEP 4 Thoroughly clean surface of the frame with supplied alcohol pads where the covers will be installed.

STEP 5 Remove the backing from the adhesive pad installed on the upper end of the cover. Slip the cover into place, being careful to hold the upper end of the cover away from the frame as you maneuver it into position. Line up the holes in the frame cover with the holes in the frame and fasten with the screws provided. Place a dab of the enclosed anti-seize on each screw prior to installation. Thread them in fully, but do not tighten them at this time.

STEP 6 Once the screws are installed in the mounting holes, press the upper section of the cover into place and apply pressure for approximately 15 seconds to ensure proper adhesion.

STEP 7 Carefully tighten the mounting fasteners. Do not over tighten. (See PIC.4.)

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

PIC 3



PIC 4

