

••••

BRAKE COVER FOR V-STAR

4029

FOR V-STAR

FITS:V-STAR 650, 1100, AND 2000-UP HONDA SABRE

PARTS INCLUDED

- 1 Brake Cover Assembly
- 1 Instruction Sheet

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

9/64", 3/32" Allen wrenches.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Separate the two halves of the brake pedal cover. Make sure the rubbers protrude evenly through the openings in the brake cover top.

STEP 2 Sandwich the stock brake pedal tread between the top and bottom halves. The brake lever must pass through the opening in the bottom half of the cover.

STEP 3 Secure the top to the bottom using the two screws that were removed in STEP 1.

STEP 4 Any free play in the cover can be removed by tightening the set screws in the back half of the cover. Be careful not to overtighten the set screws or you make damage the cover.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

Ride On!