



FLAG WITH 1/2" VERTICAL MOUNT

4254

PARTS INCLUDED

- 1 Flag Mount
- 1 Flag Mount Clamp
- 2 #8-32 X 3/4" Socket Head Cap Screws—Assembled in Clamp
- 1 Flag Pole
- 1 Flag Pole Cap
- 1 American Flag
- 1 P.O.W. / M.I.A. Flag
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.
CAUTION	This indication alerts you to the fact that ignoring the contents described herein can result in potential injury.

NOTICE	IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.
---------------	---

TOOLS SUGGESTED

Set of Hex Wrenches, Set of Combination Wrenches, Blue Thread Locker

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

NOTE: This is a universal mount that clamps to 1/2" tubing

CAUTION	Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.
----------------	--

STEP 2 Decide on a suitable location, making sure it will not interfere with the safe operation of your motorcycle.

NOTICE

Determine the mounting location and orientation of the Flag Pole Clamp before fully tightening the fasteners. The Flag Pole Clamp may leave marks when tightened down.

NOTICE

Ensure that BLUE thread locker is applied to all threaded fasteners before installation.

STEP 3 Remove the #8-32 x 3/4" socket head cap screws from the clamp and separate the halves. PIC 1

STEP 4 Place both halves of the clamp around the desire location making sure the larger hole in the clamp faces up. PIC 2 Place a drop of Blue thread locker on each of the #8 socket head cap screws and assemble the clamp base.

STEP 5 Place a drop of BLUE thread locker on the threads of the Flag Pole and thread it into the clamp. Wrap a thin piece of masking tape over the flats in the Flag Pole to help prevent scratching it. PIC 3 and PIC 4 Using an open end wrench, gently snug the Pole in the clamp. **DO NOT over tighten.**

STEP 6 Choose which flag you wish to display and install it by sliding the flag onto the pole.

STEP 7 Place a drop of BLUE thread locker on the top threads of the Flag Pole and thread the Flag Pole Cap onto the Flag Pole. Wrap a thin piece of masking tape over the flats on the Flag Pole Cap to help prevent scratching it. PIC 3 and PIC 5 Using an open end wrench, gently snug the Flag pole Cap to the flag Pole. **DO NOT over tighten, the Cap is plastic.**

NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not provide warranty coverage on products or components lost due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.

