



PREMIUM MINI BOARD with MALE MOUNT

4392


PARTS INCLUDED

- 2 Premium Mini Board Assemblies with Male Mounts
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND NOTICES REGARDING THE USE AND CARE OF THIS PRODUCT.

 WARNING	THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.
NOTICE	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTICE	IF INSTALLING THIS PRODUCT FOR ANOTHER PARTY, PLEASE MAKE SURE THEY RECEIVE THIS COPY OF THE INSTALLATION INSTRUCTIONS SO THEY ARE AWARE OF THE IMPORTANT INFORMATION CONTAINED IN THEM.
---------------	---

TOOLS SUGGESTED

Set of Hex Wrenches, Combination Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.
- STEP 2** Remove the stock peg from the peg mount. Pay attention to any spacers or washers installed between the peg mount and the clevis, it may be helpful later. Keep the mounting hardware, it will be reused.
- STEP 3** Line up the new Mini Board mount hole with the hole in the clevis. Install the new Mini Board using any spacers or washers removed in Step 2. Check that the Mini Board is able to fold upward. Tighten securely.

STEP 4

There are three mounting holes with splines around them in the Mini Board. You may use these to locate the Board forward or rearward, tilt up or down, from the stock peg (center) location. To adjust the Mini Board, remove the 5/16"-18 socket head cap screw and washer from the Mini Board. This will leave the adapter on the motorcycle. Choose your location and orientation of the Mini Board. Insert the 5/16"-18 socket head cap screw, with flat washer, through the Mini Board and thread it into the mount making sure the splines on the Mini Board are engaged in the splines on the mount in the desired location. Tighten securely.

⚠ WARNING

ENSURE THAT THE INSTALLATION OF THESE MINI BOARDS DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE BEFORE RIDING. INTERFERENCE WITH THE CONTROLS OR ANY COMPONENT ON THE MOTORCYCLE MAY CAUSE LOSS OF CONTROL RESULTING IN SERIOUS INJURY OR DEATH.

NOTICE

It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

*Ride On!***PAGE****2****PREMIUM MINI BOARDS****INSTALLATION**