



**ZOMBIE™ BRAKE PEDAL PAD**

**4405**

**FITS: ALL FXST, FXDWG AND KURYAKYN FORWARD CONTROLS**

**PARTS INCLUDED**

- 1 Zombie Brake Pedal Pad
- 1 Emblem
- 1 Hardware Kit, including:
  - 1 5/16-24 x 5/8 Socket Head Cap Screw (SHCS)
  - 1 5/16" Split Lock Washer
  - 1 Flat Washer
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**TOOLS SUGGESTED**

Set of hex wrenches, combination wrenches or socket set and ratchet, 5/16 drill bit and drill (depending on model or if motorcycle is equipped with Kuryakyn forward controls (P/N 9068, 9069, 9063 or 9064).

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

**STEP 2** Remove the stock brake lever cover. Peel the rubber off the lever or remove the acorn nut and washer. Set the cover and hardware aside, it will not be re-used.

**STEP 3** Determine if hole in the brake pedal is 1/4" or 5/16" diameter. You may have to enlarge the hole to 5/16" diameter on some models or if the bike is equipped with Kuryakyn forward controls (P/N 9068, 9069, 9063 or 9064).

**-cont.-**

**STEP 4** Slide the Zombie Brake Pedal Pad over the brake lever and align the holes. See [PIC.1](#).

**STEP 5** Place the emblem in the pad and secure it to the brake lever with the included 5/16-18 SHCS, 5/16" split lock washer and flat washer. See [PIC.1](#).

**STEP 6** Adjust the position of the pad and tighten the screw from STEP 5.

**STEP 7** Ensure proper clearance and operation before riding the motorcycle.

**WARNING!** IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

**ATTENTION!** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

**PIC.1**



*Ride On!*

**PAGE**

**2**

**ZOMBIE BRAKE PEDAL PAD    INSTALLATION**