

INSTALLATION

PILOT BRAKE PEDAL PAD

FITS ALL FXST MODELS, ALL FXDWG MODELS, AND ALL KURYAKYN FORWARD CONTROLS.

PART #	INCLUDED	
	1	Pilot Brake Pedal Cover
304429	1	Instruction Sheet

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Küryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

TOOLS SUGGESTED

Allen wrenches, needlenose pliers.

PROCEDURE – INSTALLATION

STEP 1 Remove the stock brake lever pad.

STEP 2 Install the new pilot brake pedal cover and secure with the supplied set screw.



4429

PROCEDURE — REPLACING THE RUBBER GRIPS

STEP 1 Remove the set screws from the brake pedal body.

STEP 2 The rubber grips are held in place with a pin; you must cut away the existing

rubber grips to access the pin. Remove the pin from the pedal body with needlenose pliers.

STEP 3 Apply a small amount of adhesive to the labeled tabs on each rubber grip. Install the rubber grips in the correct position (see <u>PIC.2</u>); press the labeled tabs firmly against the inside of the brake pedal body to adhere.

STEP 4 Lock the grips in place with the pin; feed the pin through the holes in the pedal body and each of the rubber grips. Take care not to bend the pin.

STEP 5 Replace the three set screws.

Ride On!

