



**PASSENGER FLOORBOARDS**

**4455**

**FITS: UNIVERSAL APPLICATIONS – REQUIRES MODEL SPECIFIC SPLINED ADAPTERS, SOLD SEPARATELY REFER TO KURYAKYN'S FULL-LINE CATALOGS FOR ADAPTER APPLICATION INFORMATION.**

**PARTS INCLUDED**

- 1 Right Side Passenger Floorboard
- 1 Left Side Passenger Floorboard
- 1 Hardware Kit, including:
  - 2 5/16-18 x 3/4 Socket Head Cap Screw (SHCS)
  - 2 Anti-Seize Packet
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KURYAKYN!**

**IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.**

**WARNING!** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION!** This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

**ATTENTION!** This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

**TOOLS SUGGESTED**

Set of hex wrenches

**STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.**

**PROCEDURE**

**STEP 1** Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

**STEP 2** Remove the existing passenger footrests; save the mounting hardware for later use.

**STEP 3** Install the model specific adapters (sold separately) and secure with the hardware from STEP 2. Refer to the instructions included with the new adapters for more information.

**-cont.-**

**NOTE** Some adapters include hardware and do not utilize the original fasteners.

**ATTENTION!** Ensure that the supplied anti-seize is applied to all threaded fasteners before installation; this will make future removal of the fasteners easier.

**STEP 4** Put a small amount of the included anti-seize on one of the 5/16-18 SHCS.

**STEP 5** Hold the Passenger Floorboards in position and insert screw from STEP 4 as shown in PIC.1. Do not thread the screw in all the way to allow for adjustment of the floorboard.

**STEP 6** Adjust the angle of the floorboard for comfort and clearance; tighten the screw from STEP 4 and STEP 5. Ensure that the splines on the Passenger Floorboard and the splined adapter fully engage when the screw is tightened.

**CAUTION!** Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

**STEP 7** Repeat STEP 4 through STEP 6 for the other side.

**WARNING!** IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

**ATTENTION!** It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

**Kuryakyn**

**PIC.1**



*Ride On!*

**PAGE**

**2**

**PASSENGER FLOORBOARDS INSTALLATION**