



EXTENDED BRAKE PEDAL

4456

FOR FL

FITS: ALL H-D DRESSER, ROAD KING AND FLST MODELS

PARTS INCLUDED

- 1 Top Cage
- 1 Bottom Cage
- 1 Rubber Pad
- 1 1 x 3.75" Double-Sided Adhesive
- 1 Hardware Kit Including:
 - 4 8-32 x 7/16" Button Socket Cap Screws (BSCS)
- 1 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

TOOLS SUGGESTED

Set of hex wrenches, spray lubricant (WD-40®, JB 80, etc.)

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface; turn off the ignition and allow the engine to cool.

WARNING! YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

-cont.-

STEP 2 Lift up on the inside edge of the brake pad and spray a lubricant on both the top and bottom side of the pad; slide the pad off the brake lever.

STEP 3 Wipe off any excess lubricant with a rag.

STEP 4 Place the rubber pads in the upper cage.

STEP 5 Place the upper and lower cage over the brake lever (the end of the cages that has a notch in them goes towards the motorcycle).

STEP 6 Secure the halves together using the 8-32 x 7/16" BSCS screws from the hardware kit ([PIC. 1](#)).

NOTE: If there is play in the cover once it has been installed, remove the cover and install the included double-sided adhesive following [STEP 7](#) through [STEP 9](#).

STEP 7 Clean the area on the inside of the bottom cage with the included alcohol-cleaning pad as well as the bottom side of the lever and allow the areas to dry.

STEP 8 Using the back of your fingernail, rub the backing of the adhesive to activate the catalyst, remove the backing and place the adhesive strip on the inside of the bottom cage as shown in [PIC. 2](#).

ATTENTION! Ensure the area of installation is free of grease, oil, dirt or other debris to ensure proper adhesion. Küryakyn WILL NOT warranty any parts lost due to improper installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50° F. Do not attempt this installation in temperatures less than 50° F.

STEP 9 Using the back of your fingernail, rub the backing of the installed adhesive strip to activate the catalyst, remove the backing and re-install the brake cover assembly.

STEP 10 Test the brake lever to make sure that there is enough clearance for the lever to operate properly.

CAUTION! Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

ATTENTION! It is the installer's responsibility to ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not warranty components lost due to improper installation. Periodic maintenance may be required.

Küryakyn®

PIC. 1



PIC. 2



Ride On!

PAGE

2

EXTENDED BRAKE PEDAL INSTALLATION