

INSTALLATION INSTRUCTIONS

INTERNAL SADDLEBAG ORGANIZER

5287

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Internal Saddlebag Organizer One
- 1 Internal Saddlebag Organizer Two
- 4 4" x 2" Adhesive Backed Loop Strips
- 2 Alcohol Pad

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

Note: Saddlebag organizers are interchangeable between saddlebags. Placement and use of organizers is up to the user. Once installed, due to the hook and loop fasteners, organizers have the ability to be switched between saddlebags.

STEP 2

Thoroughly clean the inside of the saddlebags with the included alcohol cleaning pads and allow it to dry.

NOTICE

ENSURE THE AREA OF INSTALLATION IS FREE OF GREASE, OIL, DIRT OR OTHER DEBRIS INCLUDING WAX/POLISH PRODUCTS AND BUGS TO ENSURE PROPER ADHESION. KURYAKYN WILL NOT ISSUE A WARRANTY ON ANY PARTS LOST DUE TO IMPROPER INSTALLATION.

STEP 3

Refer to PIC 2 and 3. Place the Adhesive Backed Loop Strips on the back of the Saddlebag Organizers' pre-attached hook strips.

NOTICE

THE ADHESIVE WILL NOT BOND CORRECTLY IF APPLIED AT TEMPERATURES LESS THAN 50°F. DO NOT ATTEMPT THIS INSTALLATION IN TEMPERATURES LESS THAN 50°F.

STEP 4

Using the back of your fingernail, rub the backing of the adhesive to activate the catalyst.

STEP 5

Remove the backing from the loop strips.

STEP 6

Refer to PIC 4 and 5. Align the organizer with the inside forward facing panel of a saddlebag. Put the organizer in place, press and rub the locations of the adhesive strips to secure it to the inside of the saddlebag.



PIC 1

PIC 2

PIC 3



PIC 4

PIC 5



INSTALLATION INSTRUCTIONS

INTERNAL SADDLEBAG ORGANIZER

5287

-CONTINUED-

STEP 7 Refer to PIC 5 and 7. Carefully remove the saddlebag organizer, being careful not to peel the adhesive strips off the inside of the saddlebag.

STEP 8 Rub the loop strips to ensure that they are secured to the inside of the saddlebag. Full bonding strength will occur in 24 hours. DO NOT reattach the Saddlebag Organizer until the loop strips have had the full curing time.

- FEATURES**
- Zippered pocket keeps small items secure
 - Expanding pockets hold a variety of items including a water bottle
 - Elastic MOLLE secures tools, pens, any number of items
 - Slip pockets provide flat storage for maps, phones, etc.

⚠ WARNING

ALWAYS FOLLOW MANUFACTURER'S RECOMMENDATIONS ON YOUR SADDLEBAG FOR LOAD LIMITS. LOAD ONLY IN COMPLIANCE WITH YOUR VEHICLE OWNER'S MANUAL. OVERLOADING THE SADDLEBAG MAY CAUSE LOSS OF CONTROL RESULTING IN SERIOUS INJURY OR DEATH.

