

INSTALLATION INSTRUCTIONS

XKURSION XB FAST LANE SADDLEBAGS

5293

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|----------------------------------|---|---------------------------------------|
| 1 | Throw-Over Left Saddlebag | 4 | Strap - Double Snap Hooks with Buckle |
| 1 | Throw-Over Right Saddlebag | 2 | Strap - Single Snap Hook with Buckle |
| 2 | Rain Covers | 2 | Strap - Hook & Loop with Snap Hook |
| 1 | Strap - Removable Shoulder Strap | 1 | Strap - Seat Strap |

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

CAUTION KURYAKYN IS NOT RESPONSIBLE FOR IMPROPER LOADS OR UNSAFE POSITIONING OF THE XKURSION XB FAST LANE SADDLEBAGS. BE SURE THE WEIGHT OF THE CONTENTS IN THE BAG DOES NOT EXCEED SAFE LIMITS. IT IS THE RIDERS RESPONSIBILITY TO DETERMINE WHAT THE SAFE LIMIT IS BASED ON THE POSITION OF THE BAG, PROPER SECURING OF THE BAG AND WEIGHT LIMITS CALLED OUT BY THE MANUFACTURER OF THE MOTORCYCLE.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

WARNING PREVENT SERIOUS INJURIES AND/OR DEATH! NEVER EXCEED THE MANUFACTURER'S RECOMMENDED LOAD LIMITS FOR YOUR MOTORCYCLE! BE SURE THE SADDLEBAGS DO NOT COME INTO CONTACT WITH ANY MOVING PARTS. ALWAYS CHECK FOR PROPER CLEARANCE BEFORE RIDING!

WARNING PREVENT POTENTIAL SERIOUS INJURY! ENSURE ALL SADDLEBAG FASTENERS AND STRAPS ARE SECURE BEFORE RIDING THE MOTORCYCLE.

**RIGHT
SADDLEBAG**



**LEFT
SADDLEBAG**



**DOUBLE
SNAP
HOOKS**



**HOOK & LOOP WITH
SNAP HOOK**



SHOULDER STRAP



INSTALLATION INSTRUCTIONS

XKURSION XB FAST LANE SADDLEBAGS

5293

-CONTINUED-

FEATURES

- High contrast visibility liner
- Grey reflective elements on the outside of the bag
- Reflective rain covers, and its own stowaway pockets
- Glove friendly zipper pulls
- G-Hook straps for external coat storage
- Custom anti-scratch welded D-rings (4 per bag)
- Full mounting strap kit
- Low-profile MOLLE for small accessory attachments
- Molded organizer pocket for additional protection
- 2" expansion zipper
- 12" tablet storage with additional media storage
- Forward facing, easy to access bottle pockets
- Low-profile carrying handles and removable shoulder strap
- Quick, removable seat straps
- Designed to fit around rear lighting systems

MOUNTING SUGGESTIONS

- The saddlebags fit either over or under the passenger seat. The saddlebags can be positioned with the narrow wedge end facing either forward or backward, depending on the best fit for your application.
- Use the adjustable straps and the hook and loop fastener clip straps to secure the saddlebags to your motorcycle. DO NOT secure the saddlebags to the swingarm or any other part that moves independently from the seat. Be sure that the straps will not become tangled in any moving parts before riding.
- The saddle strap between the tops of the saddlebags is adjustable, allowing the bags to fit many applications. Separate the hook and loop fastener flaps and reposition to adjust the width. Be sure that the width between the saddlebags is not so loose that a saddlebag could get caught under the fender or in the wheel. Always check for proper clearance before riding. Allow for at least 4" clearance from exhaust pipe.
- The saddlebags are equipped with multiple steel D-rings allowing you to get the best fit for your application. Slide the steel D-rings into the elastic pockets when not in use to eliminate rattling due to vibration. Slide the cable lock through the D-rings to secure the saddlebags to your motorcycle.



WARNING

AFTER INSTALLING THE SADDLEBAGS, BE SURE TO CHECK FOR PROPER CLEARANCE BETWEEN THE BAG AND ANY MOVING PARTS, INCLUDING THE WHEELS AND SWING ARM. NEVER PLACE THE ANCHORING STRAPS NEAR THE WHEELS OR BRAKE CALIPERS. BE SURE THE PLACEMENT OF THE SADDLEBAGS DOES NOT INTERFERE WITH SAFE OPERATION OF THE MOTORCYCLE.

NOTICE

THE SADDLEBAGS HAVE HEAT-RESISTANT SHIELDS BUT WE DO NOT RECOMMEND PLACING THE BAGS NEAR EXHAUST PIPES. BE SURE TO MAINTAIN PROPER CLEARANCE AWAY FROM EXHAUST PIPES. ALLOW FOR AT LEAST 4" CLEARANCE FROM EXHAUST PIPE.



INSTALLATION INSTRUCTIONS

XKURSION XB FAST LANE SADDLEBAGS

5293

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.
