

INSTALLATION INSTRUCTIONS

REMOVABLE BACKREST PAD

5299

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Removable Backrest Pad

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

Note: The Filler Pad is intended to be used with any Kuryakyn Momentum or XKursion bag (sold separately).

MOUNTING SUGGESTIONS

- Determine desired position for the backrest pad.
- Unfasten hook and loop straps needed for desired mounting position
- Insert hook and loop straps through MOLLE loops on Kuryakyn Momentum or XKursion bags, or to quick-release sissy bar straps, and secure them together tightly.

FEATURES

- Multi-fit attachment system mounts to any Kuryakyn Momentum and XKursion luggage
- The removable pad is contoured and ergonomic design keeps you on the road longer
- Hook and loop attachment leaves endless amounts of mounting options
- Premium vinyl construction retains its shape and is UV-tested

PIC 1



PIC 2



TOP TO BOTTOM MOUNTING

PIC 3



PIC 4



LEFT TO RIGHT MOUNTING

PIC 5





INSTALLATION INSTRUCTIONS

REMOVABLE BACKREST PAD

5299

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.
