

INSTALLATION INSTRUCTIONS

SPEAR MINI BOARDS WITHOUT ADAPTERS, CHROME

5652

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

1	Right Side Spear Mini Board	1	Hardware Kit
1	Left Side Spear Mini Board	2	Flat Washers
		2	5/16-18 x 1 Socket Head Cap Screws

YOU WILL ALSO NEED:

Set of hex wrenches, combination wrenches

Peg Adapters for your specific motorcycle model and year (sold separately)

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

WARNING THE END USER'S SAFETY DEPENDS UPON PROPER INSTALLATION OF THIS PRODUCT. IF A STEP IN THESE INSTRUCTIONS IS NOT WITHIN YOUR CAPABILITIES OR YOU DO NOT HAVE THE CORRECT TOOLS, HAVE YOUR DEALER PERFORM THE PROCEDURE. IMPROPER INSTALLATION OF THIS PRODUCT COULD RESULT IN DEATH OR SERIOUS INJURY.

BEFORE RIDING, ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE.

THE BOARDS MUST BE INSTALLED SO THEY WILL FOLD UPWARD AND REARWARD IF THEY COME IN CONTACT WITH ANY OBJECT. FAILURE TO INSTALL AND ADJUST THE BOARDS TO OPERATE IN THIS MANNER MAY CAUSE LOSS OF CONTROL RESULTING IN SERIOUS INJURY OR DEATH.

PRE-INSTALLATION CONSIDERATION

The Mini Boards were designed to be used in many different locations on a variety of motorcycles. These installation instructions contain specific mounting procedures as well as general guidelines for comfortable and safe installation of the boards.

DRIVER FOOTBOARD APPLICATIONS: Ensure that the installation of the boards does not prohibit the proper function of the gear shifter or rear brake pedal. You may only be able to use the middle or front mounting hole to keep the board from extending too far forward thereby reducing gear shift-er or brake pedal clearance.

PASSENGER FOOTBOARD APPLICATIONS: The boards can be installed so that they fold up in the stow position. Ensure that, when folded back, the boards do not contact any part of the motorcycle and that they remain in the stowed position during operation of the bike.

INSTALLATION INSTRUCTIONS

SPEAR MINI BOARDS WITHOUT ADAPTERS, CHROME

5652

-CONTINUED-

INSTALL FOOTPEG ADAPTERS: Refer to the installation instructions included with the new footpeg adapters (sold separately).

INSTALL THE MINI BOARDS:

NOTE: Refer to PIC 1. Locate the brake-side (right) Mini Board installation.

Refer to PIC 2. Determine which of the three splined mounting holes will best suit you BEFORE continuing on.

STEP 2 Position the Mini Board on the footpeg adapter. Install the included 5/16" screw with flat washer, through the Board and into the adapter.

STEP 3 Thread the screw into the Adapter until it is snug. Ensure that the Board is able to fold upward and rearward.

STEP 4 Ensure the splines on the Board and Adapter are engaged and tighten the screw securely.

STEP 5 Repeat STEPS 2 through 4 for the clutch-side (left).

ADJUST THE MINI BOARD ANGLE:

STEP 6 Refer to PIC 2. Loosen (but do not remove) the 5/16" screw. Adjust the angle to the desired position. Ensure that the splines are engaged and retighten the screw.

STEP 7 Fold the board up and ensure that it does not contact any part of the bike. Adjust if necessary.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

