

INSTALLATION INSTRUCTIONS

HORN COVER MOUNT FOR INDIAN® MODELS

5759

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Horn Cover Mount
- 3 M6 x 1 x 40mm Socket Head Cap Screws
- 1 M6 x 1 x 12mm Flat Head Socket Cap Screw

YOU WILL ALSO NEED:

Metric hex wrench set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Remove existing horn cover and mounting hardware. Set them aside, they will not be reused.

STEP 3 Locate provided Horn Cover Mount and one (1) M6 Flat Head Socket Cap Screw.

STEP 4 Refer to PIC 3. Align the Horn Cover Mount with the mounting holes where the existing horn cover was attached. Fasten the very bottom mounting hole of the Horn Cover Mount to the motorcycle using the flat head screw.

STEP 5 Refer to PIC 4. Locate horn cover (sold separately) and provided three (3) M6 Socket Head Cap Screws. Align the horn cover over the Horn Cover Mount. Only using one (1) of the screws, lightly fasten the bottom of the cover to the mount.



M6 X 1 X 40MM SHCS



M6 X 1 X 12MM FHSCS

PIC 1



PIC 2



PIC 3



PIC 4

INSTALLATION INSTRUCTIONS

HORN COVER MOUNT FOR INDIAN® MODELS

5759

-CONTINUED-

STEP 6

Make sure all of the remaining mounting holes of the cover and cover mount are aligned with the mounting holes on the motorcycle. Once aligned, fasten the cover to the mount and motorcycle. Fully tighten all hardware.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

