

INSTALLATION INSTRUCTIONS

PHANTOM FOOTPEGS WITHOUT ADAPTERS, CHROME

5760

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right Peg without Adapters
- 1 Left Peg without Adapters
- 2 5/16-18 X .875 Socket Head Cap Screws

YOU WILL ALSO NEED:

Hex wrench set, combination wrench set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

Note: These pegs require the separate purchase of the appropriate Kuryakyn footpeg adapter for your model.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Remove existing hardware and peg from clevis. Set clevis/mounting hardware aside, it will be reused.

STEP 3 Refer to PIC 2. Install the new peg adapter as per the instructions with the peg adapter. Check that the peg adapter is installed correctly and the adapter is able to fold upward.

WARNING FOOTPEGS MUST BE INSTALLED SO THEY WILL FOLD UPWARD AND REARWARD IF HIT BY ANY OBJECT. FAILURE TO ADJUST THE FOOTPEGS TO OPERATE IN THIS MANNER COULD RESULT IN SERIOUS INJURY OR DEATH.



INSTALLATION INSTRUCTIONS

PHANTOM FOOTPEGS WITHOUT ADAPTERS, CHROME

5760

-CONTINUED-

STEP 4 Refer to PIC 3 and 4. Locate one (1) provided Peg and Socket Head Cap Screw. Position the peg on the peg adapter and insert the screw into the mounting hole located on the bottom of the peg. Loosely fasten the peg to the peg adapter.

STEP 5 Set the footpeg to desired position, and tighten the socket head cap screw; the peg adapter will seat itself into the peg and keep it from rotating. Fully tighten all hardware.

STEP 6 Repeat Steps 2 through 5 for the opposite side.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 4



FINAL