

INSTALLATION INSTRUCTIONS

PHANTOM DRIVER FLOORBOARDS FOR INDIAN®, GLOSS BLACK

5771

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Right Driver Floorboard
- 1 Left Driver Floorboard

YOU WILL ALSO NEED:

Combination wrench set, socket set and ratchet, ft-lbs (Nm) torque wrench

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.



STEP 2 Refer to PIC 2. Remove existing hardware and floorboard from the floorboard mounting bracket. Set the hardware aside, it will be reused.



STEP 3 Refer to PIC 3. Located provided Driver Floor Board. Align and place the floorboard onto the driver floorboard mount.



INSTALLATION INSTRUCTIONS

PHANTOM DRIVER FLOORBOARDS FOR INDIAN®, GLOSS BLACK

5771

-CONTINUED-

- STEP 4** Refer to PIC 4. Locate hardware that was removed in Step 2. Insert the bolt through the aligned front mounting holes. Press it all the way through. Fasten it in place with the lock not removed in Step 2.

TORQUE VALUE FOR FLOORBOARD MOUNTING HARDWARE:
18FT-LBS (24.4NM)

- STEP 5** Repeat steps 2 through 4 on the opposite side.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 4



FINAL