

INSTALLATION INSTRUCTIONS

MICRO RACK

5782 CHROME OR 5783 BLACK

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|-----------------|---|---|
| 1 | Micro Rack | 1 | 1/4"-20 X 3/4" Torx Button Head Cap Screw (HD only) |
| 2 | Rubber Adhesive | 1 | M8 x 1.25 X 20mm Torx Button Head Cap Screw (Indian only) |
| | | 1 | 1/4" Flat washer (HD only) |

YOU WILL ALSO NEED:

Torx wrench set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** Refer to PIC 2. Locate provided Micro Rack and two (2) rubber adhesive strips. Remove and discard the backing from adhesive strips. On the bottom side of the rack align and place a strip on either side of the mounting holes. Press rubber adhesive strips into place.
- STEP 3** Remove the motorcycle seat's existing thumb nut and additional hardware.
FOR HD ONLY: set all hardware aside, it will not be reused.
FOR INDIAN ONLY: set the flat washer aside, it will be reused.
- STEP 4** Determine which torx screw is needed to be used with your motorcycle.
FOR HD ONLY: locate provided flat washer and place it onto the appropriate torx screw.
FOR INDIAN ONLY: locate OEM flat washer, that was removed in Step 3, and place it on the appropriate torx screw.
- STEP 5** Lift the rear of the seat, align and place the rack under the seat. Determine desired position of rack. Align the rack's mounting hole with the thumb nut mounting hole.
- STEP 6** Refer to PIC 3. Secure rack and seat in place using the torx screw and flat washer assembly. Fully tighten all hardware.





INSTALLATION INSTRUCTIONS

MICRO RACK

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.