

INSTALLATION INSTRUCTIONS

HEX DRIVER FLOORBOARDS, SATIN BLACK

5901

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|-------------------------|---|----------------------------|
| 1 | Left Driver Floorboard | 1 | Hardware Kit, containing: |
| 1 | Right Driver Floorboard | 4 | 1/4-20 X 1" Shoulder Screw |
| | | 4 | 1/4-20 Lock Nut |

YOU WILL ALSO NEED:

Socket set and ratchet, hex wrench set

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Remove existing floorboard mounting hardware and floorboard from the mounting brackets. Set it all aside, they will not be reused.

STEP 3 Locate provided Driver Floorboard. Align and place the floorboard on the mounts.

STEP 4 Refer to PIC 4. Locate provided two (2) screws and two (2) locking nuts.



INSTALLATION INSTRUCTIONS

HEX DRIVER FLOORBOARDS, SATIN BLACK

5901

-CONTINUED-

- STEP 5** Refer to PIC 5 and 6. Insert the screw through the aligned floorboard and mounting bracket mounting holes. Secure the floorboard to the mounting bracket by fastening a lock nut to the screw. Fully tighten the hardware, **BUT DO NOT OVER TIGHTEN.**

Note: Refer to PIC 5. The screw fastening to the front mount should be inserted from the front, and the screw fastening to the rear mount should be inserted from the rear.

- STEP 6** Repeat steps 2 through 5 on the opposite side.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

