

INSTALLATION INSTRUCTIONS

HEX PASSENGER BOARD INSERTS, CHROME

5902

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Passenger Board Insert

YOU WILL ALSO NEED:

Flat blade screwdriver, dish soap

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.



PIC 1

STEP 2 Refer to PIC 2 and 3. Remove the existing passenger board insert by gently pulling up on the insert while simultaneously pushing on the rubber darts protruding from the bottom of the floorboard pan.



PIC 2



PIC 3

STEP 3 Refer to PIC 4. Locate provided Passenger Board Inserts; apply a little dish soap to the rubber darts to ease installation; align the two (2) darts over the existing floorboard pan.



PIC 4

STEP 4 Refer to PIC 5 and 6. Press downward on the insert and GENTLY pull the two (2) rubber darts through the bottom of the floorboard pan. Ensure that the darts have been completely pulled through the hole.



PIC 5



PIC 6

STEP 5 Repeat for the opposite side.

INSTALLATION INSTRUCTIONS

HEX PASSENGER BOARD INSERTS, CHROME

5902

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

