

## INSTALLATION INSTRUCTIONS

### HEX BRAKE PEDAL PAD FOR FL, CHROME

5914

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- |   |              |   |                                 |
|---|--------------|---|---------------------------------|
| 1 | FL Brake Pad | 1 | Hardware Kit, containing:       |
|   |              | 1 | Fender Washer                   |
|   |              | 1 | 1/4" Split Lock Washer          |
|   |              | 1 | 1/4-20 X 3/8 Hex Head Cap Screw |

#### YOU WILL ALSO NEED:

Socket set and ratchet

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

**WARNING** YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

**STEP 2** Remove existing brake pedal pad. Set it aside, it will not be reused.

**STEP 3** Locate provided FL Brake Pedal Pad. Align and place over brake lever.

**STEP 4** Refer to PIC 4. Locate provided Fender Washer and Button Socket Cap Screw. Place the Split Lock Washer onto the Hex Head Cap Screw, followed by the Fender Washer.

**STEP 5** Refer to PIC 5. Insert the screw and washer assembly through the mounting hole on the bottom of the brake pedal and pedal pad. Fully tighten hardware.



## INSTALLATION INSTRUCTIONS

### HEX BRAKE PEDAL PAD FOR FL, CHROME

5914

-CONTINUED-

#### NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

