



STILETTO END CAPS, GLOSS BLACK

6359

Thank You For Choosing Kuryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Stiletto End Caps
- 8 #4-40 X 9/16" Socket Head Cap Screws
- 8 #4-40 x 3/4" Socket Head Cap Screws

YOU WILL ALSO NEED:

Set of Hex Wrenches

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

- STEP 1 Read and understand all STEPS in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn IGN OFF.
- STEP 2 Remove the existing end caps from the ISO-Grips.
- STEP 3 Remove the trim rings from the existing end caps; place them on the included Stiletto End Caps.
- STEP 4 Install the Stiletto End Cap assembly on each ISO-Grip; secure with the included #4-40 x 9/16" Socket Head Cap Screws. For ISO-Grips with ISO Throttle Boss; secure with the included #4-40 X 3/4" Socket Head Cap Screws.

NOTICE

It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.