

INSTALLATION INSTRUCTIONS

PRECISION UPPER FRAME COVER, CHROME

6419

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|-------------------|---|---------------------------------------|
| 1 | Upper Frame Cover | 1 | Hardware Kit, containing: |
| | | 1 | Grommet |
| | | 2 | 1/4-20 x 1-1/2" Socket Head Cap Screw |
| | | 2 | 1/4" Flat Washer |
| | | 2 | 1/4-20 Hex Nut |

YOU WILL ALSO NEED:

Set of combination wrenches, set of hex keys

PICTURES SHOWN ARE OF THE BLACK PARTS. INSTALLATION OF THE CHROME PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

WARNING A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Remove the existing upper screws from the voltage regulator mount; set them aside they will NOT be reused.

STEP 3 Refer to PIC 2. Locate the provided Grommet. Insert the grommet into the hole located at the peak of the frame downtubes.



INSTALLATION INSTRUCTIONS

PRECISION UPPER FRAME COVER, CHROME

6419

-CONTINUED-

- STEP 4** Refer to PIC 3. Locate the provided Upper Frame Cover. Align and place the lower mounting brackets of the frame behind the frame downtube. Align the boss, located on the top back side of the Upper Frame Cover, with the grommet and press it into place.

Note: If being installed with the Precision Regulator Cover P/N 6427 or 6428 (sold separately) and/or the Precision Oil Cooler Cover P/N 6417 or 6418 (sold separately) install covers in the following order:

- 1st - Oil Cooler Cover
- 2nd - Regulator Cover (but not the hardware)
- 3rd - Upper Frame Cover

- STEP 5** Refer to PIC 4 and 5. Locate two (2) provided Socket Head Cap Screws, Flat Washers, and Hex Nuts. Insert the screws through the frame downtube upper mounting holes and cover(s). On the backside of the downtube place the washers followed by the hex nuts onto the protruding screws. Fully tighten hardware.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 3



PIC 4

BACKSIDE OF COVER AND
HARDWARE ASSEMBLY
OFF-BIKE VIEW



PIC 5