

INSTALLATION INSTRUCTIONS

PRECISION™ LOWER FRONT FRAME COVER FOR TOURING, CHROME

6423

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Lower Frame Cover
- 1 3/8-16 X 2.25" Socket Head Cap Screw

YOU WILL ALSO NEED:

Hex wrench set, hex bit socket set, in-lbs (Nm) torque wrench

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Remove existing hardware from the upper left corner of the jiffy stand, located above the floorboard's left forward bracket or footrest bracket.

Note: You can remove the entire floorboard and mounting bracket assembly to gain easier access to the lower front primary chaincase area. Refer to your motorcycle's service manual for assistance in removal of floorboard and mounts.

STEP 3 Locate provided Lower Frame Cover. Align the mounting holes of the cover with the jiffy stand hole and primary chaincase housing hole.

Note: Wiring harness, connected by Xmas Tree Clip Zip Tie, may need to be removed to maneuver the cover. Remove with proper tool, otherwise Xmas tree clip could get destroyed.

STEP 4 Locate provided screw. Insert the screw into the lower left mounting hole to fasten the cover to the jiffy stand. Fully tighten hardware.

TORQUE VALUE FOR JIFFY STAND SCREW:
144-156 IN-LBS (16.3-17.6 NM)

STEP 5 Reinstall any additional items that may have been removed during the process.

PIC 1



PIC 2



PIC 3





INSTALLATION INSTRUCTIONS

PRECISION™ LOWER FRONT FRAME COVER FOR TOURING, CHROME

6423

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.
