

INSTALLATION INSTRUCTIONS

PRECISION™ SPARK PLUG COVERS FOR MILWAUKEE-EIGHT®, GLOSS BLACK

6444

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

2 Spark Plug Covers

YOU WILL ALSO NEED:

Hex Key Set

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.
- STEP 2** Refer to PIC 1 and 4. Locate one (1) provided Spark Plug Cover. Remove the set screws from the cover. To access the hardware insert a 1/8 hex key into the small holes located on the top back side of the cover. Apply a drop of blue (medium strength) thread locker onto to the set screws, and then reinstall them into the cover.
- STEP 3** Refer to PIC 2. On the top of the cylinder head, align and place one of the Spark Plug Covers in the open space around the spark plug.
- STEP 4** Refer to PIC 3 and 4. Secure the cover in place by tightening the set screws located within the cover. Tighten hardware until the cover is secure.

PIC 1



PIC 2



PIC 3



PIC 4

OFF-BIKE
BACK
VIEW



INSTALLATION INSTRUCTIONS

PRECISION™ SPARK PLUG COVERS FOR MILWAUKEE-EIGHT®, GLOSS BLACK

6444

-CONTINUED-

STEP 5 Repeat Steps 2 through 4 for the remaining Spark Plug Cover.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

