

INSTALLATION INSTRUCTIONS

PRECISION™ CYLINDER BASE COVER FOR SOFTAIL, GLOSS BLACK

6453

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|---------------------|---|---------------------------------------|
| 1 | Cylinder Base Cover | 1 | Hardware Kit, containing: |
| | | 1 | 5/16"-18 X 3.5" Socket Head Cap Screw |
| | | 1 | 5/16" Flat Washer |

YOU WILL ALSO NEED:

Set of hex wrenches, set of hex bit sockets, ft-lbs (Nm) torque wrench

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

WARNING A FACTORY SERVICE MANUAL WILL BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN. IMPROPER INSTALLATION COULD RESULT IN SERIOUS INJURY OR DEATH.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

STEP 2 Refer to PIC 2. Disconnect the shift linkage rod from the shifter rod lever to gain access to the crank case.

STEP 3 Refer to PIC 2. Remove the existing screw from the crankcase; set it aside it will NOT be reused.

STEP 4 Refer to PIC 3. Locate the provided Cylinder Base Cover. Align and place the cover over the crankcase base.



PIC 1



PIC 2



PIC 3

INSTALLATION INSTRUCTIONS

PRECISION™ CYLINDER BASE COVER FOR SOFTAIL, GLOSS BLACK

6453

-CONTINUED-

- STEP 4** Refer to PIC 3 and 4. Locate one (1) provided Socket Head Cap Screw and one (1) Flat Washer. Thread the washer onto the screw. Fasten the Cylinder Base Cover to the crankcase base. Fully tighten hardware.

TORQUE VALUE FOR CRANKCASE SCREW:
15-19 FT-LBS (20.3-25.8 NM)

- STEP 5** Refer to PIC 4. Reinstall the shift linkage rod to the shifter rod lever.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.



PIC 4