

INSTALLATION INSTRUCTIONS

DILLINGER PEGS WITH MALE MOUNT ADAPTERS, SATIN BLACK

6667

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Pegs with Adapters

YOU WILL ALSO NEED:

Hex wrench set, combination wrench set

PICTURES SHOWN ARE OF THE SILVER PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

PIC 1



WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Refer to PIC 2. Remove existing hardware and peg from clevis. Set hardware aside, it will be reused.

PIC 2



Note: Pay attention to any spacers or washers installed between the male mount on the peg and the clevis. Placement of that hardware may be helpful later.

STEP 3 Refer to PIC 3. Locate a provided Peg with Adapter. Align the holes of the male mount adapter, attached to the new peg, with the holes of the clevis.

PIC 3



Note: If applicable, reinstall washers or spacers that were removed from Step 2 at this time.

STEP 4 Refer to PIC 4. With the peg folded up, use the original hardware from Step 2 to secure the peg to the clevis. Tighten all hardware securely. Check that the peg is installed correctly and is able to fold down.

PIC 4



WARNING FOOTPEGS MUST BE INSTALLED SO THEY WILL FOLD UPWARD AND REARWARD IF HIT BY ANY OBJECT. FAILURE TO ADJUST THE FOOTPEGS TO OPERATE IN THIS MANNER COULD RESULT IN SERIOUS INJURY OR DEATH.

INSTALLATION INSTRUCTIONS

DILLINGER PEGS WITH MALE MOUNT ADAPTERS, SATIN BLACK

6667

-CONTINUED-

- STEP 5** Loosen the socket head cap screw located on the bottom of the peg. Set the footpeg to desired position.
- STEP 6** Re-tighten the socket head cap screw; the peg adapter will seat itself into the peg and keep it from rotating. Fully tighten all hardware.
- STEP 7** Repeat Steps 2 through 6 for the opposite side.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

