

INSTALLATION INSTRUCTIONS

ISO GRIPS FOR HD WITH HEATED GRIPS

6780 CHROME OR 6781 GLOSS BLACK

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE

THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

1	Clutch Top Half	1	Clutch Endcap (numbers etched on it)
1	Throttle Top Half	1	Throttle Endcap
2	Bottom Halves	8	M4 x .07 x 16mm Socket Head Cap Screws
		1	Endcap Adhesive

YOU WILL ALSO NEED:

Metric hex wrench set, blue loctite

NOTICE

THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1

Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

NOTICE

- CLUTCH TOP HALF = receives mounting hardware, has an etched arrow on endcap side
- THROTTLE TOP HALF = receives mounting hardware, blank
- BOTTOM HALVES = hardware mounts through this half
- CLUTCH ENDCAP = numbers etched into it
- THROTTLE ENDCAP = blank

STEP 2

Separate the bottom halves from the top halves, and the endcaps from the halves. Set them aside for now.

STEP 3

Locate provided Clutch Endcap (with etched numbers on it) and Endcap Adhesive. Remove the backers from the adhesive piece and place it on the inside of the Clutch Endcap.

STEP 4

On the clutch side of the motorcycle, align the power symbol on the Clutch Endcap with the zero or power symbol on the existing heated grip, and press the endcap onto the end of the grip.

STEP 5

Located provided Clutch Top Half, a Bottom Half, and four (4) screws. Apply a small amount of blue loctite to the threads of the screws.



INSTALLATION INSTRUCTIONS

ISO GRIPS FOR HD WITH HEATED GRIPS

-CONTINUED-

STEP 6 Refer to PIC 2. Locate the etched arrow on the end of the Clutch Top Half. Align it with the power symbol on the end cap, and place it over the existing grip. Be sure the endcap is seated into the groove of the Clutch Top Half.

STEP 7 On the empty half of the clutch grip, align the bottom half with the Clutch Top Half. Loosely secure the halves together using the provided screws. Be sure the halves are still properly aligned with the endcap (arrow of the Top half should be aligned with the power symbol). Fully tighten hardware.

STEP 8 Locate provided Throttle Top Half, the other Bottom Half, the Throttle Endcap, and four (4) screws. Apply a small amount of blue loctite to the threads of the screws.

STEP 9 Refer to PIC 3. Align and place the endcap into the grooves on the inside of the Throttle Top Half. Be sure the note on the endcap sets into the notch in the groove of the Top Half.

STEP 10 Align the assembly over the existing grip. Align the Bottom half with the Top Half and loosely fasten with the screws. Look at the alignment of the clutch grip and make position adjustments to the throttle grip as needed. Fully tighten hardware.

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

