

INSTALLATION INSTRUCTIONS

TRI-LINE SADDLEBAG HINGE COVERS, GLOSS BLACK

6987

Thank You For Choosing Küryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.



THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

NOTICE

This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Left Tri-Line Hinge Cover
- Right Tri-Line Hinge Cover

YOU WILL ALSO NEED:

Set of Torx Drivers

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its importance for future use.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn IGN OFF.

NOTICE

Avoid damage to the motorcycle. Protect painted surfaces with a soft cloth or blanket.

- STEP 2 Open the left saddlebag lid. Remove the two screws securing the lid tether as shown in PIC 1. Keep the screws, they will be reused.

 Keep hold of the lid once the tether has been released.
- STEP 3 Remove the three (3) screws securing the existing hinge cover; set the cover aside, it will not be reused. Keep the screws, they will be reused.
- STEP 4 Align the Left Saddlebag Hinge Cover with the three holes in the hinge. Secure the Cover with the three (3) screws from the previous STEP.
- STEP 5 Reattach the lid tether; close the lid.
- STEP 6 Repeat STEPS 2 –5 for the right side.



