

INSTALLATION INSTRUCTIONS

HEAVY INDUSTRY SHIFT PEG, CHROME

7035

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|--------------------------|---|---------------------------------------|
| 1 | Heavy Industry Shift Peg | 1 | Hardware Kit, containing: |
| | | 1 | 5/16 Internal-Tooth Lock Washers |
| | | 1 | 5/16-24, 2.75" Socket Head Cap Screws |

YOU WILL ALSO NEED:

Hex Key Set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Remove existing shift peg using a hex key, turning it counter-clockwise. Set peg aside, it will not be reused.

STEP 3 Locate the heavy industry shift peg and 5/16-24 socket head cap screw. Insert the screw into the indented hole of the shift peg.

STEP 4 Locate the 5/16 internal-tooth lock washer. Place washer over the threads of the socket head cap screw.



INSTALLATION INSTRUCTIONS

HEAVY INDUSTRY SHIFT PEG, CHROME

7035

-CONTINUED-

- STEP 5** Align and fasten shift peg assembly to shift lever. Adjust the shift peg to desired position. Using a hex wrench, tighten the 5/16-24 socket head cap screw on the end of the peg.

NOTICE

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

