

INSTALLATION INSTRUCTIONS

HEAVY INDUSTRY BRAKE PEDAL PAD, FL, CHROME

7039

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|-------------------------------|---|------------------------------------|
| 1 | Heavy Industry FL Brake Pedal | 1 | Hardware Kit, containing: |
| | | 1 | 5/16 Lock Washer |
| | | 1 | 5/16-18 x 3/4" Hex Head Cap Screws |
| | | 1 | 5/16 Fender Washer |

YOU WILL ALSO NEED:

Socket set

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

WARNING YOU WILL BE WORKING AROUND THE ENGINE AND EXHAUST SYSTEM DURING INSTALLATION. ENSURE THAT THE ENGINE AND EXHAUST SYSTEM HAVE FULLY COOLED TO PREVENT INJURY.

STEP 2 Remove existing break pad from brake lever.

STEP 3 Locate heavy industry FL brake pedal. Align and place over brake lever.

STEP 5 Locate hardware kit. Place 5/16 lock wash onto 5/16-18 x 3/4" hex head cap screw, followed by the 5/16 fender washer. Secure the brake pad to the brake pedal by fastening the hardware assemble on the back side of the brake pedal. Tighten the hardware by using a 1/2" socket.



INSTALLATION INSTRUCTIONS

HEAVY INDUSTRY BRAKE PEDAL PAD, FL, CHROME

7039

-CONTINUED-

NOTICE

IT IS THE END USER'S RESPONSIBILITY TO ENSURE THAT ALL FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST OR DAMAGED DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

