

## INSTALLATION INSTRUCTIONS

### HEAVY INDUSTRY FOLDING BOARDS, CHROME

7045

#### THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

**WARNING** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

**CAUTION** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

**NOTICE** THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

#### ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- |   |                          |   |                                      |
|---|--------------------------|---|--------------------------------------|
| 1 | Right Side Folding Board | 1 | Hardware Kit, containing:            |
| 1 | Left Side Folding Board  | 2 | 5/16 -18 X 1" Socket Head Cap Screws |
|   |                          | 2 | Flat Washers                         |

#### YOU WILL ALSO NEED:

Set of hex wrenches, combination wrenches  
Peg Adapters for your specific motorcycle model and year (sold separately)

**NOTICE** THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

**WARNING** THE END USER'S SAFETY DEPENDS UPON PROPER INSTALLATION OF THIS PRODUCT. IF A STEP IN THESE INSTRUCTIONS IS NOT WITHIN YOUR CAPABILITIES OR YOU DO NOT HAVE THE CORRECT TOOLS, HAVE YOUR DEALER PERFORM THE PROCEDURE. IMPROPER INSTALLATION OF THIS PRODUCT COULD RESULT IN DEATH OR SERIOUS INJURY.

**WARNING** BEFORE RIDING, ENSURE THAT THE INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE.

**NOTICE** PLACING THESE FLOORBOARDS ON MOUNTS INTENDED FOR FOOTPEGS MAY PROHIBIT THEM FROM FOLDING UP IN THE SAME MANNER AS THE STOCK PEG. ALSO, IF THE BOARD IS POSITIONED SO IT WILL FOLD UP AS STOCK, THE TRAILING END OF THE BOARD MAY BE IN A POSITION THAT COULD LIMIT CORNERING CLEARANCE.

**NOTICE** THE FLOORBOARD MAY BE ROTATED ON THE MOUNT FOR A COMFORTABLE FOOT POSITION, HOWEVER, SOME ANGLES MAY CAUSE THE BOARD TO CONTACT OTHER COMPONENTS ON THE BIKE BEFORE THE BOARD IS FOLDED UP COMPLETELY. BEFORE INSTALLING, BE AWARE OF COMPONENTS ON THE BIKE THAT MAY INTERFERE WITH THE PLACEMENT OF THE FLOORBOARDS.



PIC 1

## INSTALLATION INSTRUCTIONS

### HEAVY INDUSTRY FOLDING BOARDS, CHROME

7045

-CONTINUED-

#### INSTALLATION OF THE FOLDING BOARDS

- STEP 2** Remove the existing footpegs and install the splined adapters (sold separately) onto the footpeg mounts using the stock hardware. Refer to the specific instructions included with the splined adapters.
- STEP 3** Locate provided Right (brake) Side Folding Board. Align and test fit the position of the Folding Board. Determine which of the three splined mounting holes best suits you before continuing on.
- STEP 4** Locate provided one (1) screw and flat washer. Place the washer onto the screw.
- STEP 5** Refer to PIC 3. Align and place the Folding Board on the footpeg adapter. Fasten the board to the adapter using the screw and flat washer assembly. Ensure the splines on the board and adapter are engaged. Fully tighten hardware.
- STEP 6** Ensure that the board is able to fold upward.
- STEP 7** Repeat Steps 3 through 6 for the Left (clutch) Side Folding Board.



#### ADJUSTING THE FOLDING BOARDS

- STEP 8** Loosen (but do not remove) the screw. Adjust the angle of the board to the desired position. Ensure that the splines are engaged and re-tighten the screw.
- STEP 9** Fold the board up and ensure that it does not contact any part of the bike. Adjust if necessary.

#### NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

