

# INSTALLATION

7154

LUGGAGE RACK RISERS

FITS: ALL '01-UP GL1800'S; FOR USE WITH KÜRYAKYN LUGGAGE RACK P/N 7151. UNIVERSAL FIT APPLICATION ON 1/2" TUBE RACK LEGS.

# PARTS INCLUDED

- 4 Luggage Rack Spacer
- 1 Hardware Kit including:
- 2 #10-24 x 2" BSCS
- 2 #10-24 x 1-3/4" BSCS
- 4 Spacer, .2 x .75 x .125
- 4 Spacer, .2 x 1.00 x .125
- 4 1/4" SAE Flat washer
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

# THANK YOU FOR CHOOSING KÜRYAKYN!

#### PLEASE NOTE

It is the installers' responsibility to make sure all fasteners (including pre-assembled) are tightened before operation of motorcycle. Küryakyn will not warranty components that are lost due to improper installation. Periodic maintenance may be required.

## **TOOLS SUGGESTED**

Phillips screwdriver, set of hex wrenches, 1/4" drill bit and drill,

ATTENTION! A factory service manual may be helpful in performing this installation. Do not attempt to perform this installation if you are not confident in your ability to complete all steps in the procedure; consult a trained technician.

ATTENTION! This procedure requires making permanent modifications to the trunk lid; this may void your warranty. Consult your dealer for more information.

CAUTION! AVOID POTENTIAL ELECTRICAL SHOCK! BE SURE TO DISCONNECT THE BATTERY BEFORE STARTING THIS PROCEDURE.

## PROCEDURE

**STEP 1** Park motorcycle on a hard, level surface. Shut the ignition off. If equipped, put the motorcycle on center-stand.

**STEP 2** Disconnect the battery.

**STEP 3** Open the top trunk lid; remove the 15 screws securing the plastic underside of the lid. Save the hardware for later use. See <u>PIC.1</u>.

**STEP 4** Remove the two screws on each latch ring. See <u>PIC.1</u>.



SCREWS SECURING UNDERSIDE OF LID ARE MARKED WITH AN X

-cont.-

**STEP 5** Pull the trunk lid underside down; disconnect the multi-pin connector. See <u>PIC.2</u>.

**STEP 6** Set aside the trunk lid underside.

**STEP 7** Remove the existing luggage rack and hardware; save for later use. It is recommended that the existing rack mount holes in the trunk lid be enlarged with a 1/4" drill bit to allow for alignment and ease of installation.

**NOTE** For installation where a trunk spoiler is already installed, ensure that there is enough clearance to install rack risers before drilling any holes.

**STEP 8** Insert a 1-3/4" screw, washer and small rubber spacer through the underside of the trunk lid in one of the front holes. See <u>FIG.1</u>.

**STEP 9** Install a large rubber spacer and rack riser over the protruding end of the screw on the topside of the trunk lid. See <u>PIC.3</u>, <u>PIC.4</u> and <u>FIG.1</u>.

**STEP 10** Repeat STEP 8 and STEP 9 for the other front hole.

**STEP 11** Carefully hold the rack in position and begin the threads of the screws into the rack; do not fully tighten the screws. Allow the rack to "hang" while the rear screws are prepared. See <u>PIC.5</u>.

**STEP 12** Install a 2" screw, washer, small rubber spacer through one of the rear holes in the trunk lid.

**STEP 13** Place large rubber spacer and rack riser over the protruding end of the screw; repeat for the other side.

**STEP 14** Thread the rear screws into the rack. Do not fully tighten screws.

STEP 15 Close trunk lid; center rack on lid

STEP 16 Carefully open the lid; tighten screws.





PIC.3

DEPRESS TAB

