

INSTALLATION INSTRUCTIONS

TOUR-PAK LID GRIP, TOURING '14-UP, GLOSS BLACK

7163

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Tour-Pak Lid Grip

YOU WILL ALSO NEED:

Torx wrench set

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

STEP 2 Refer to PIC 1, 2 and 3. Unlatch and open Tour-Pak. From the top half of the Tour-Pak remove four (4) existing screws from Tour-Pak Latch. Remove the latch. Set hardware aside until Step 3, where it will be reused.

STEP 3 Refer to PIC 4 and 5. Locate Tour-Pak Lid Grip. Align it with the four screw holes on the Tour-Pak. Attach lid grip to Tour-Pak using the screws that were removed in Step 2. Tighten all hardware.

Note: Gently pull back and down on the Tour-Pak gasket while installing the hardware. This will help prevent the gasket from getting pinched between the hardware and the Tour-Pak.



PIC 1



PIC 2



PIC 3



PIC 4



PIC 5

INSTALLATION INSTRUCTIONS

TOUR-PAK LID GRIP, TOURING '14-UP, GLOSS BLACK

7163

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.

