



# TRI-LINE GAUGE TRIM

7284

THANK YOU FOR CHOOSING KÜRYAKYN!

PROTECT YOURSELF AND OTHERS FROM POSSIBLE INJURY AND PROPERTY DAMAGE OR LOSS. PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS, AND NOTICES REGARDING THE INSTALLATION, USE, AND CARE OF THIS PRODUCT.

<b>NOTICE</b>	This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.
---------------	---

MAKE SURE THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 1 Tri-Line Gauge Trim
- 1 Alcohol Pad
- 1 Installation instructions

**TOOLS SUGGESTED:**

Warm soapy water and a clean rag

**STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition.

<b>NOTICE</b>	<p>Ensure proper adhesion of this product. Clean the installation area of grease, oil, bugs, dirt and other debris (including wax and polish). Kuryakyn WILL NOT issue a warranty for any improperly installed products.</p> <p>Do not attempt this installation in temperatures below 50° F. Proper adhesive bonding ONLY occurs above 50° F.</p>
---------------	--

**STEP 2** Refer to **PIC 1**. Using warm soapy water and a clean rag, remove all dirt and debris from the installation area (in blue); allow the area to dry completely. Wipe the installation area with the included alcohol pad to remove any wax or polish; allow the area to dry completely.



**STEP 3** Test fit the Tri-Line Gauge Trim as shown in **PIC 2**. Hold the bottom of the trim against the fairing, then press in at the top. Remove the Gauge Trim after you are comfortable with test fit.



**STEP 4** Use your fingernail to rub the adhesive backing; this will activate the adhesive. Remove and discard the backing.

**STEP 5** Align the Trim on the fairing. Press the bottom, top and sides into place for one minute; full bonding will occur after 24 hours.

**NOTE:** If the bike is going to be operated before full bonding occurs, secure the Trim to the fairing with a good quality masking or painter's tape.

*Ride On!*