



**TRICEPTOR FENDER ACCENT**

**7340**

**HONDA: ALL '01-UP GL1800, VTX1800 AND 1300  
YAMAHA: ALL V-STAR 1300, 1100 AND 650, ALL '99-UP ROAD STAR, ALL ROADLINER  
AND STRATOLINER  
UNIVERSAL: 4" OR WIDER STYLE FENDERS (DOES NOT FIT FENDERS WITH FLAT  
CENTER WIDTH)**

**PARTS INCLUDED**

- 1 Triceptor Fender Accent
- 1 Alcohol Pad
- 1 Installation Instructions

*Please read and understand entire instructions before starting installation.*

**THANK YOU FOR CHOOSING KÜRYAKYN!**

**CAUTION!** Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

**ATTENTION!** Be sure the area is free of grease, oil, dirt, or other debris to ensure proper adhesion. Kuryakyn WILL NOT warranty any parts lost due to improper installation.

**ATTENTION!** The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

**NOTE** Installation is shown on a VTX1800F; while representative of typical procedure, there may be minor differences when installed on other models.

**NOTE** Before you install the Triceptor Fender Accent, determine your preferred mounting location. Suggested mounting locations are shown in PIC.1.

**NOTE** Remove the locating tabs with a pair of needle nose pliers, if necessary, for proper fit. Bend the tabs back and forth until they release; carefully cut the remaining tab base until it is flush with a razor blade.

**NOTE** The Triceptor Fender Accent was designed to flex and bend to follow the contour of a fender. Ensure that the entire piece is pressed into place.

**TOOLS SUGGESTED**

Soapy water and clean rag.

**PROCEDURE**

**STEP 1** Clean the mounting location thoroughly with soapy water and a clean rag.

**PIC.1**



**STEP 2** Clean the mounting location with the included Alcohol Pad and allow to dry completely.

**-cont.-**

**STEP 3** Rub the adhesive backing to activate the adhesive. See [PIC.2](#).

**STEP 4** Remove the adhesive backing.

**STEP 5** Position the Triceptor Fender Accent on the fender and press down on the entire piece for at least 60 seconds for the best adhesion. Full bond strength will occur within 24 hours.

**NOTE** Press the center of the Triceptor Fender Accent into place first and then the outsides to ensure full adhesive bond.

*Ride On!*

**Kuryakyn**

**PIC.2**



**PAGE**

**2**

**TRICEPTOR FENDER ACCENT**

**INSTALLATION**