



FRONT FENDER TIP

7344

**FITS: UNIVERSAL FOR 6" WIDE OR WIDER CURVED FENDERS WITHOUT A CENTER RIDGE.
ALL HONDA VTX 1800 C, F AND VTX 1300 C
ALL '99-UP YAMAHA ROAD STAR AND V-STAR 1300**

PARTS INCLUDED

- 1 Front Fender Tip with Adhesive
- 1 Alcohol Cleaning Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

WARNING! IMPROPER INSTALLATION OR USE OF THIS PRODUCT COULD RESULT IN SERIOUS INJURY OR DEATH.

CAUTION! This indication alerts you to the fact that ignoring the contents described herein can result in potential injury or material damage.

CAUTION! Ensure that the installation of this product does not interfere with the proper operation of the motorcycle before riding.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

ATTENTION! Ensure the area of installation is free of grease, oil, dirt, or other debris to ensure proper adhesion. Kuryakyn WILL NOT warranty any parts lost due to improper installation.

ATTENTION! The adhesive will not bond correctly if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

NOTE Installation is shown on a 2002 Honda VTX 1800C; while representative of typical procedure, there may be minor differences when installed on other models.

TOOLS SUGGESTED

Soapy water and a clean rag

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

BEFORE INSTALLATION Pre-fit the Front Fender Tip on your front fender.

If there is a gap at the outer edges of the fender tip greater than the thickness of a penny, the fender tip **WILL NOT** properly install on your motorcycle.

STEP 1 Park the motorcycle on a hard, level surface; turn off the ignition

STEP 2 Pre-fit the Front Fender Tip on your front fender. See Pic. 1.

STEP 3 Remove any grease or debris from the installation area with soapy water and a clean rag; allow the area to dry completely.

ATTENTION! Thoroughly clean the area of installation of grease, oil, dirt, or other debris to ensure proper adhesion. Küryakyn **WILL NOT** warranty any parts lost due to improper installation.

ATTENTION! The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

STEP 4 Clean the area with the included alcohol cleaning pad; allow the area to dry completely.

STEP 5 Rub the backing on the adhesive strip to activate the adhesive before applying.

STEP 6 Hold in place for 1 minute to ensure proper adhesion. Full bond strength will occur within 24 hours.

STEP 7 Ensure proper clearance and operation before riding the motorcycle.

Ride On!

Küryakyn

PIC.1



PAGE

2

FRONT FENDER TIP **INSTALLATION**