

INSTALLATION INSTRUCTIONS

REAR SPEAKER ACCENTS FOR '14-UP TOURING & TRIKE

7376

Thank You For Choosing Küryakyn!

Protect yourself and others from potential injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.



This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality or damage the product itself or the product to which it is being attached.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- 2 Rear Speaker Accents
- 1 Installation Instructions

YOU WILL ALSO NEED:

T10 Torx driver

NOTICE

These installation instructions contain important information. Ensure that the end user receives this copy and is aware of its

- STEP 1 Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn IGN OFF.
- STEP 2 Refer to PIC 1. Use a T10 Torx driver to remove the four screws securing the cover to the speaker pod.
- **STEP 3** Remove and discard the existing cover; save the four screws.
- STEP 4 Refer to PIC 2. Align the Speaker Accent and speaker with the holes; secure it with the four screws.
- STEP 5 Repeat for the other side.

NOTICE

It is the end user's responsibility to ensure that all fasteners (including pre-assembled) are tightened before operation of the motorcycle. Kuryakyn will not provide warranty coverage on products or components lost or damaged due to improper installation or lack of maintenance. Periodic inspection and maintenance are required on all fasteners.



