

INSTALLATION INSTRUCTIONS

HYPERCHARGER™ ES HORN COVER, SATIN BLACK

7491

THANK YOU FOR CHOOSING KURYAKYN!

Protect yourself and others from possible injury and property damage or loss. Pay close attention to all instructions, warnings, cautions, and notices regarding the installation, use, and care of this product.

WARNING THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN POTENTIAL DEATH OR SERIOUS INJURY.

CAUTION THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN CAN RESULT IN MINOR OR MODERATE POTENTIAL INJURY.

NOTICE THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING THE CONTENTS DESCRIBED HEREIN MAY NEGATIVELY AFFECT PRODUCT PERFORMANCE AND FUNCTIONALITY OR DAMAGE THE PRODUCT ITSELF OR THE PRODUCT TO WHICH IT IS BEING ATTACHED.

ENSURE THAT THE FOLLOWING PARTS HAVE BEEN INCLUDED IN THE KIT:

- | | | | |
|---|------------|---|------------------------------------|
| 1 | Horn Cover | 1 | Hardware Kit, containing: |
| | | 1 | 5/16" Internal Tooth Lock Washer |
| | | 1 | 5/16 x 1" Socket Head Cap Screw |
| | | 1 | 5/16-18 x 2" Barrel Nut |
| | | 2 | 8-32 X 0.5" Button Head Cap Screws |
| | | 1 | Bracket |

YOU WILL ALSO NEED:

Hex bit socket set, socket set or combination wrench set, in-lbs (Nm) torque wrench

PICTURES SHOWN ARE OF THE CHROME PARTS. INSTALLATION OF THE BLACK PARTS WILL BE THE SAME.

NOTICE THESE INSTALLATION INSTRUCTIONS CONTAIN IMPORTANT INFORMATION. ENSURE THE END USER RECEIVES THIS COPY AND IS AWARE OF ITS IMPORTANCE FOR FUTURE USE.

- STEP 1** Read and understand all steps in the instructions before starting the installation. Park the motorcycle on a hard, level surface and turn off the ignition. Let motorcycle cool.

NOTICE A FACTORY SERVICE MANUAL MAY BE HELPFUL IN PERFORMING THIS INSTALLATION. DO NOT ATTEMPT TO PERFORM THIS INSTALLATION IF YOU ARE NOT CONFIDENT IN YOUR ABILITY TO COMPLETE ALL OF THE STEPS IN THE PROCEDURE; CONSULT A TRAINED TECHNICIAN.

- STEP 2** Test the horn. The horn should sound the same with the new Horn Cover installed.

- STEP 3** Remove the acorn nut and washer that attaches the stock horn cover and horn assembly to the rubber mount on the motorcycle. Set hardware aside, it will NOT be reused. Unplug the wires from the back of the horn and remove the horn from the motorcycle.

- STEP 4** Remove the flange nut that secures the horn to the existing horn cover. Pay attention to the position of the wire connections and the bell, it will be installed on the new bracket in the same orientation. Set the flange nut aside, it will be reused. Remove the horn from the existing cover.



INSTALLATION INSTRUCTIONS

HYPERCHARGER™ ES HORN COVER, SATIN BLACK

7491

-CONTINUED-

STEP 5 Refer to PIC 3 and 4. Locate provided Horn Cover and bracket. Lightly fasten the horn to the bracket using the flange nut that was removed in Step 4.



STEP 6 Refer to PIC 5. Place the horn and bracket assembly inside of the horn cover, with the longer arm in the upper left corner and shorter arm in the lower right corner. Adjust the position of the horn to be sure the terminal connect points of the horn are pointing down towards the ground. Fully tighten the flange nut to secure the horn in place.



TORQUE VALUE FOR FLANGE NUT:
80-100 IN-LBS (9-11.3 NM)

STEP 7 Refer to PIC 6. Locate provided Horn Cover and two (2) Button Head Cap Screws. Fasten the horn and bracket assembly to the Horn Cover.



STEP 8 Refer to PIC 7. Locate provided Barrel Nut. Fasten it to the rubber mount stud, from where the existing horn cover was removed from.



TORQUE VALUE FOR BARREL NUT:
35-55 IN-LBS (3.9-6.2 NM)

STEP 9 Refer to PIC 8. Locate provided internal tooth lock washer and socket head cap screw. Insert the screw through the mounting hole on the front top side of the horn cover. On the inside of the horn cover, thread the lock washer onto the screw.



STEP 10 Refer to PIC 8. Reattach the horn wires to the terminal connect points on the horn.

STEP 11 Refer to PIC 9. Align the horn cover assembly over the barrel nut. Fasten assembly to the barrel nut. Fully tighten hardware.



TORQUE VALUE FOR SOCKET SCREW:
80-120 IN-LBS (9-13.6 NM)

STEP 12 Reinstall main fuse and test the horn.



INSTALLATION INSTRUCTIONS

HYPERCHARGER™ ES HORN COVER, SATIN BLACK

7491

-CONTINUED-

NOTICE

IT IS THE INSTALLER'S RESPONSIBILITY TO ENSURE THAT ALL OF THE FASTENERS (INCLUDING PRE-ASSEMBLED) ARE TIGHTENED BEFORE OPERATION OF THE MOTORCYCLE. KURYAKYN WILL NOT PROVIDE WARRANTY COVERAGE ON PRODUCTS OR COMPONENTS LOST DUE TO IMPROPER INSTALLATION OR LACK OF MAINTENANCE. PERIODIC INSPECTION AND MAINTENANCE ARE REQUIRED ON ALL FASTENERS.