

PREMIUM EXTENDED BRAKE PEDAL PAD

7587

PARTS INCLUDED

Premium Extended Brake Pedal Assembly for Harley Davidson ®

Hardware Kit Containing 1

5/16" Fender Washer

5/16" Lock Washer 5/16"-18 Acorn Nut

Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

WARNING! THIS INDICATION ALERTS YOU TO THE FACT THAT IGNORING

THE CONTENTS DESCRIBED HEREIN CAN RESULT IN

POTENTIAL DEATH OR SERIOUS INJURY.

ATTENTION! This indication alerts you to the fact that ignoring the contents

described herein may negatively affect product performance and

functionality.

TOOLS SUGGESTED

Set of Combination Wrenches

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

STEP 1 Read and understand all steps in the instructions before starting the

installation. Park the motorcycle on a hard, level surface and turn off the

ignition. Remove the stock brake pedal pad.

STEP 2 Align the chrome brake pad base to the brake pedal. PIC 1 Insert the stud on

the Rubber Pad through the Chrome Base so it protrudes out the back of the brake pedal.

PIC 1

STEP 3 Install the Fender Washer, then the Lock Washer, then the Acorn nut. PIC 2 As

you tighten the Acorn nut, make sure that the Rubber Pad stays square in the recessed portion of the Chrome Base.

Tighten securely.

ATTENTION! It is the installer's responsibility to

ensure that all of the fasteners (including pre-assembled) are tightened before operation of the motorcycle. Küryakyn will not issue a warranty on components lost due to

improper installation. Periodic maintenance may be required.

WARNING! ENSURE THAT THE

INSTALLATION OF THIS PRODUCT DOES NOT INTERFERE WITH THE PROPER OPERATION OF THE MOTORCYCLE BRAKE

PEDAL BEFORE RIDING.



INSERT STUD ON RUBBER PAD HERE

